

## Construction Tips in Termite Management Area

The Ontario Building Code requires:

- Bottom step of stair stringer must rest on concrete
- Decks and porches must be on min. 6" concrete
- Footing or pier wood elements between 6-18" must be pressure treated
- There must be a minimum 18" clearance

## Construction Tips in Termite Management Area

- No wood retaining walls
- No wood floor sheds
- New wood fence posts must be on metal brackets
- Firewood/lumber, etc. must be stacked off the ground